





# INSTRUCTION MANUAL

# CHC-00 CENTREUCALPUME





### IM 70023-US7 S 9709

G&H RESERVE THE RIGHT TO MINOR CHANGES IN DESIGN AND FUNCTION

## Introduction

#### Thank you for purchasing a G&H product.

This manual has been provided to instruct you how to operate and service this product correctly and safely. Be sure to follow all directions and instructions; failure to do so could result in personal injury or equipment damage.

This manual should be considered part of this product and should remain with it at all times for reference. (If you sell it, please be sure to include this manual with it).

**Warranty** is provided as part of G&H Products Corp.'s commitment to our customers who operate and maintain their equipment as this manual dictates. Failure to do so may result in loss of warranty.

Where defects appear on the product during the warranty period, G&H Products Corp. will back the product and correct the problem. Should the equipment be modified or not kept in the manner prescribed within this manual, the warranty will become null and void.

Copyright © 1997 G&H Products Corp.



## **Table of Contents**

This manual is divided into main sections See below.	Please note that the drawing on page 17 can support the reading of the manual.
Safety	1. Warning Signs 2 2. Safety Precautions 3
Installation	1. Unpacking/Delivery42. Installation53. Pre-Use Check6
Operation	1. Operation/Control72. Troubleshooting83. Recommended Cleaning9
Maintenance	<ol> <li>General Maintenance</li></ol>
Technical Data	1. Technical Data 16
Drawings/Parts List	1. Exploded View 17 2. Drawing/Parts List 19
Information	1. Notes



## Safety

Throughout each of G&H Product Corp's instruction manuals, certain safety signal words and symbols will appear. These are in the form of, warning, caution or note

### WARNING!

CAUTION!

NOTE!

- : Indicates that special procedures **must** be followed to avoid severe personal injury.
- : Indicates that special procedures **must** be followed to avoid damage to the equipment.
- : Denotes actions or procedures to follow for optimum, safe use of equipment.

#### Follow Safety Directions

Read this manual thoroughly before working on equipment.

Leave all safety stickers on equipment and keep them maintained in legible condition. In the event that stickers become damaged or are missing, contact G&H Products Corp. for replacements.

Maintain equipment in good working condition.

#### **Do Not Make Machine Modifications**

G&H Products Corp. offers a full range of products to suit all of your needs. Therefore, product modification is never necessary.

#### **Keep Maintenance Safe**

Replace damaged or worn parts immediately. Never allow old product, debris, or any lubricants to build up on equipment. Never operate unless equipment is in proper working order.

Before attempting to service the machine, disconnect all power and compressed air. Allow machine to come to a complete stop. Never service a machine while it is operating. Keep all limbs away from moving equipment. Be sure that product pressure has been relieved before beginning maintenance.

### 1. Warning Signs





- : General warning.
- Dangerous electrical voltage.
- Caustic agents.

## Safety

: Always observe the technical data (see page 16). : : the direction of rotation. the pump casing removed. : : ing hot liquids or when sterilizing. : the pressure side blocked. : : : is serviced. : proposition of when the man 1-

### 2. Safety Precaulions

Installation:







**Operation:** 









### **Maintenance:**







CONTACT CSI FOR MORE INFORMATION | CSIDESIGNS.COM | SALES@CSIDESIGNS.COM | 417.831.1411

The pump must be electrically connected by authorized personnel (see the motor instructions).

Pay special attention to the instructions below so that

severe personal injury or damage to the pump are

avoided.

- GHC-00 with impeller of AISI 316L (optional)
  - Always remove the impeller before checking
  - Never start the pump if the impeller is fitted and
- Always observe the technical data (see page 16).
- Never touch the pump or the pipelines when pump-
- Never run the pump with both the suction side and
- Always handle caustic and acid with great care.

- Always observe the technical data (see page 16).
- Always disconnect the power supply when the pump
- The pump must **never** be hot when serviced. The pump and the pipelines must never be



( (

## Installation

The instruction manual is part of the delivery. Read the instructions carefully.

## 1. Unpacking/Delivery

## 1

#### NOTE!

G&H cannot be held responsible for incorrect unpacking.

#### Check the delivery:

- 1. Complete pump, GHC-00.
- 2. Packing list.
- 3. Instruction manual.
- 4. Motor instructions.
- 5. Test certificate, IF ORDERED!

GHC-00:Impeller and collets of fiberglass reinforced plastic. Option: Impeller of AISI 316L and yoke of AISI 304. The standard delivery does not include the test certificate. This can be supplied on request.

2

4



Clean the inlet and the outlet from possible packing materials.





Inspect the pump for visible transport damage.



Avoid damaging the inlet and the outlet.



Read the instructions carefully and pay special attention to the warnings!

Always check the pump before operation. - See pre-use check on page 6. **NOTICE:** Please notice that the drawings below only show the principle.

2

## 2. Installation



/ţ`

 $( \bigcirc$ 

Always observe the technical data (see page 16).

The pump **must** be electrically connected by authorized personnel (see the motor instructions).

### NOTE!

G&H cannot be held responsible for incorrect installation.



Ensure that there is sufficient clearance around the pump (min. 2 ft).



SEE NOTICE!

Ensure that the flow direction is correct.

- 1. Ensure that the pipelines are routed correctly.
- 2. Ensure that the connections are tight.

5

#### **Risk of damage!**

 $\bigcirc$ 

Avoid stressing the pump. Pay special attention to:

- Vibrations.
- Thermal expansion of the tubes.
- Excessive welding.
- Overloading of the pipelines.



## Installation

Read the instructions carefully and pay special attention to the warnings!

GHC-00:Impeller and collets of fiberglass reinforced plastic. Optional:Impeller and yoke of stainless steel. Check the direction of rotation of pump shaft/motor fan before operation.

- See the indication label on the pump.

**SEE NOTICE!** 

**NOTICE:** Please notice that the drawings below only show the principle

The back of

the motor

Correct!

### 3. Pre-Use Check - GHC-00 with impeller of fiberglass reinforced plastic (std.)

See the indication label!

#### CAUTION!

Never check the direction of rotation with liquid in the pump.

- 1. Start and stop the motor momentarily.
- 2. Ensure that the direction of rotation of the motor fan is **clockwise** as viewed from the back of the motor.

### 3. Pre-Use Check - GHC-00 with impeller of AISI 316L (optional)



 Always remove the impeller before checking the direction of rotation.

- Never start the pump if the impeller is fitted and the pump casing removed.



#### See the indication label!

- 1. Start and stop the motor momentarily.
- 2. Ensure that the direction of rotation of pump shaft (26) is **counterclockwise** as viewed from the inlet side.

Disassemble the pump in accordance with instructions 1, 2,3 and 5 on page 12.





## Operation

Read the instructions carefully and pay special attention to the warnings!

The pump is fitted with a warning label indicating correct throttling. **NOTICE:** Please notice that the drawings below only show the principle.

## 1. Operation/Control

## 1

Always observe the technical data (see page 16).

### NOTE!

G&H cannot be held responsible for incorrect operation/control.



3 SEE NOTICE! Explosion danger!

SEE NOTICE!
Do not run dry
Correct!
Wrong!
CAUTION!

- The shaft seal must not run dry.

- Never throttle the inlet side.

## ٨

**Never** run the pump with both the suction side and the pressure side blocked.



### Control:

Reduce the capacity and the power consumption by means of:

- Throttling the pressure side of the pump.
- Reducing the impeller diameter.
- Speed control of the motor.



## Operation

Pay attention to possible faults.

Read the instructions carefully.

## 2. Troubleshooting

#### NOTE!

Read the maintenance instructions carefully before replacing worn parts. - See Spare Part List!

Problem	Cause/Result	Repair
Overloaded motor	<ul> <li>Pumping of viscous liquids</li> <li>Pumping of liquids with high density</li> <li>Low outlet pressure (counter pressure)</li> </ul>	<ul> <li>Reduce impeller diameter.</li> <li>Increase counter pressure (throttling)</li> </ul>
Cavitation:		
- Damage	- Low inlet pressure	- Increase the inlet pressure
<ul> <li>Pressure reduction (or total loss of pressure) (sometimes to zero)</li> <li>Elevate noise level</li> </ul>	- High liquid temperature	<ul> <li>Reduce the liquid temperature</li> <li>Reduce the pressure drop be- before the pump</li> </ul>
Leaking shaft seal	<ul> <li>Dry run (See page 7)</li> <li>Incorrect seal elastomer choice</li> <li>Abrasive particles in the liquid</li> </ul>	Replace:         All wearing parts (See Spare Part List)         - Select alternative elastomer         - Select stationary and rotating seal ring in Silicon Carbide/Silicon Carbide
Leaking seals	- Incorrect seal elastomer choice	Select an alternative elastomer



## Operation

9

The pump is designed for cleaning in place (CIP). CIP = Cleaning In Place. Read the instructions carefully and pay special attention to the warnings!

### 3. Recommended Cleaning





5

Always handle caustic and acid with great care.

0

### Examples of cleaning agents:

Use clean water, free from chlorides.

1. 1% by weight NaOH at 158°F.



2. 0.5% by weight HNO<sub>3</sub> at 158°F.

100 I = Cleaning agent. water



Always rinse well with clean water after the cleaning.



- 1. Avoid excessive concentration of the cleaning agent
  - $\Rightarrow$  Dose gradually!

NaOH = Caustic Soda.

HNO, = Nitric acid.

2. Adjust the cleaning flow to the process

Milk sterilization/viscous liquids

- $\Rightarrow$  Increase the cleaning flow!
- 6

### NOTE!

The cleaning agents must be stored/discharged in accordance with current rules/directives.

Maintain the pump carefully.

Read the instructions carefully and pay special attention to the warnings!

Always keep spare shaft seals and rubber seals in stock. See separate motor instructions. NOTICE: Please notice that the drawings below only show the principle.

## 1. General Maintenance



Always observe the technical data (see page 16).

Always disconnect the power supply when the pump is serviced.

#### NOTE!

All scrap must be stored/discharged in accordance with current rules/directives.



The pump must never be hot when serviced.



### CAUTION!

Fit the electrical connections correctly if they have been removed from the motor during service (see pre-use check on page 6).

The pump and the pipelines must never be pressurized when the pump is serviced.

### Pay special attention to the warnings!

### Ordering spare parts

- Contact the Sales Department.

- Order from the Spare Parts List.

Recommended spare parts: Service kits (see Spare Parts List).



Maintain the pump carefully. Read the instructions carefully.

 $\square$ 

Always keep spare shaft seals and rubber seals in stock. See separate motor instructions. Check the pump for smooth operation after service.

### 1. General Maintenance

	Shaft seal	Rubber seals	Motor bearings
Preventive maintenance	<b>Replace after 12</b> <b>months:</b> (one-shift) Complete shaft seal	Replace when replacing the shaft seal	
Maintenance after lea- kage (leakage normally starts slowly)	Replace at the end of the day: Complete shaft seal	Replace when replacing the shaft seal	
Planned maintenance	<ul> <li>Regular inspection for leakage and smooth operation</li> <li>Keep a record of the pump</li> <li>Use the statistics for planning of inspections</li> <li>Replace after leakage: Complete shaft seal</li> </ul>	Replace when replacing the shaft seal	Yearly inspection is recommended - Replace complete bearing if worn
Lubrication	<b>Before fitting</b> Lubricate the O-rings with silicone grease or silicone oil (not the sealing sur- faces)	Before fitting Silicone grease or sili- cone oil	None The bearings are per- permanently lubricated

11



Read the instructions carefully. The items refer to the drawings and the parts list on pages 17-19.

Handle scrap correctly.

### 2. Disassembly of Pump/Removing the Shaft Seal (1-5\*) 1 10 E -13 6р 26b **2**6a GHC-00 std.: 7 shaft (26b). Remove handles (13). 1. 2. Remove collets 14. 3. Remove pump casing (7) and O-ring (10), move it from the pump shaft (26a). (use a plastic hammer, if necessary). Use a plastic hammer if necessary. 3 24 25 23 1. stationary seal ring (23). 1. Remove back plate (9). 2. 2. The shaft seal is now accessible. from back plate (9). 5 6 7a 28 5 20 19 21 29 27

Remove the rest of the shaft seal from pump shaft

Remove screws (2) and washers (3).



1.

12



×

Remove impeller (6b) by pulling it off pump-

GHC-00 with impeller of AISI 316L (optional) .: Turn impeller (6a) counterclockwise and re-



- Turn nut (24) clockwise and remove it from
- Remove stationary seal ring (23) and seal (25)



Read the instructions carefully. The items refer to the drawings and the parts list on pages 17-19.

Handle scrap correctly.

## 2. Disassembly of Pump/Removing the Shaft Seal (1-5\*)

 Image: The second system
 Image: The second syste

Read the instructions carefully.

The items refer to the drawings and the parts list on pages 17-19.

2

### 3. Assembly of Pump/Fitting the Shaft Seal (3-8\*)

- 1. Fit pump shaft (26) on the motor shaft.
- 2. Fit thrower (5) on pump shaft (26).
- 3. Fit adaptor (4) washers (3) and screws (2). **NOTE!**

Ensure that the adaptor drain hole is turned downwards.



1. Lubricate the external surface of the pump shaft.

Fit spring (19), spacer (20) and washer (21) on pump shaft (26).



Push seal ring (27) as far as possible over O-ring (29).

#### NOTE!

3

Push and pull until the O-ring is correctly positioned.



- Fit backplate on adaptor. 25a
   Push impeller (6b) on pump shaft (26b). GHC-00 with impeller af AISI 316L (optional)
- 2b. Fit impeller (6a) on pump shaft (26a), turn it clockwise and tighten. Check the clearance between backplate (9) and the impeller (0.031-0.039) inch.
- 3. Tighten the set screws (28).
- 4. Remove the backplate, and impeller for assembly of seal.



Fit O-ring (29) on pump shaft (26). **NOTE!** 

Ensure correct position of the joint when Teflon O-rings are used.



1. Fit seal (25) and stationary seal ring (23) in back plate (9).

2. Fit nut (24), turn it **counterclockwise** and tighten.



15

### Read the instructions carefully.

The items refer to the drawings and the parts list on pages 17-19.

Lubricate the rubber seals before fitting them.

## 3. Assembly of Pump/Fitting the Shaft Seal (3-8\*)



Fit the back plate on adaptor (4).



- 1. Fit impeller (6) on pump shaft (26), check the clearance between backplate (9) and the impeller (0.031"-0.039")
- 2. Fit O-ring (10) and pump casing (7) on back plate (9).
- 3. Fit collets (14).

8

4. Fit and tighten handles (13).



## **Technical Data**

It is important to observe the technical data during installation, operation and maintenance.

Inform the personnel about the technical data.

## 1. Technical Data

#### Data

Max. inlet pressure	58 PSI
Temperature range,	+14° F to + 176°F
	+14°F to + 284°F (EPDM)
Impeller diameter,	3.74 inch.
Noise level	max. 70 dB(A)

### **Materials**

Product wetted steel parts Other steel parts Impeller, Adaptor,	AISI 316L AISI 304 Fiberglass reinforced Nylon (standard) or AISI 316L Plastic (POM) (standard) or Cast iron, zinc sprayed and coated with two-
Collets, Product wetted seals Alternative seals Finish	component lacquer Fiberglass reinforced Noryl Nitrile (standard) EPDM, Fluorinated Rubber (FPM) and Teflon (PTFE) 150 Grit Polished

### Shaft seal

Seal types	Single seal mechanical
Material, stationary seal ring	AISI 329 with sealing surface of Silicon Carbide
Material, rotating seal ring	Carbon (standard) or Silicon Carbide
Material, O-rings	Nitrile (standard)
Alternative material, O-rings	EPDM, Fluorinated Rubber (FPM) and Teflon (PTFE)

#### Motor

Standard C-faced foot mounted motor according to NEMA standard, 3600/1800 RPM 60Hz, 3 phase.

Voltage and frequency	60Hz, 230-460V Std.
Motor sizes (HP), 60Hz	1/2, 3/4, 1.

\* Other voltage and frequencies available upon request.



## **Exploded View**

The drawing includes all items of the pump.

They are identical with the items in the Spare Parts List.

This page shows an exploded drawing of GHC-00. GHC-00: Impeller and collets of fiberglass reinforced plastic. Optional: Impeller and yoke of stainless steel.

GHC-00





## Drawing/Parts List

The drawing and the parts list include all items of the pump.

The items are identical with the items in the Spare Parts List. When ordering spare parts, please use the Spare Parts List!

## **Parts List**

Pos.	Qty.	Description
1	1	Motor
2	4	Screw
3	4	Washer
4	1	Adaptor
5	1	Thrower
7	1	Pump casing
9	1	Black plate
6a	1	2 bladed impeller, stainless steel
6b	1	2 bladed impeller, glasfibre reinforced plastic
10 <b>Δ</b>	1	O-ring
12	2	Stud bolt
13	2	Handles
14	2	Collet
19 <b>Δ</b>	1	Spring
20 <b>Δ</b>	1	Spacer
21 <b>Δ</b>	1	Washer
23 <b>∆</b>	1	Stationary seal ring
24	1	Nut
25 <b>Δ</b>	1	Seal
26a	1	Pump shaft
26b	1	Pump shaft
27 <b>Δ</b>	1	Rotating seal ring
28	1	Set screw
29 <b>Δ</b>	1	O-ring
30	1	Frame
31	3	Nut
32	3	Washer
33	3	Legs

∆ : Service kit - EPDM, NBR, FPM, PTFE (See Spare Parts list)



## **Drawing/Parts List**

The drawing shows GHC-00.

The items refer to the parts list on page 18.



19