





8.1 Actuator



- = actuator service kit
- * = not used in actuator 1½" - 2"
- ** = not used in actuator 2½", 3", 4 and 6"



○ = wear parts

* = with SpiralClean in leakage chamber