## TABLE OF

## "It's stainless steel, it shouldn't rust"

This is often the kind of statements heard from individuals when discussing a failure of process piping or equipment. This is also an indication of how little is actually understood about stainless steel and the applications where it is used.

For years the food, beverage and pharmaceutical industries have used stainless steels in their process piping systems. Most of the time stainless steel components provide satisfactory results. Occasionally a catastrophic failure will occur. The purpose of the information contained within this document is to bring an understanding to stainless steel, it's uses, and why it will fail under certain conditions.

In the following pages we will discuss the different classes of stainless steel, heat treatment, corrosion, welding, and finally material selection. As with any failure, it is imperative the cause of the failure be identified before a proper fix can be recognized. Most often the cause of the failure is identified as the wrong material being used in the wrong application. We can not solve problems by using the same kind of thinking we used when we created them.

We have strived in this document to provide engineers, purchasing agents, and plant personnel with a tool to enhance their knowledge of stainless steel and its uses as related to their present and future applications.

#### Early Discovery of Stainless Steel Sets Industry in Motion

Stainless steel, the solid foundation of the sanitary industry, had a humble and practical beginning.

In 1912 while searching for a solution to erosion on gun barrels caused by the action of heat and gases during discharge, stainless steel was first discovered at Brown Firth Laboratories.

However the first, true stainless steel was melted on August 13, 1913, and contained 0.24% carbon and 12.8% chromium. Building on the discovery from Brown Firth Laboratories, Harry Brearley was still trying to develop a more wear resistant steel. In order to examine the grain structure of this newly developed steel, he needed

to etch the samples before examining them under the microscope. The etching re-agents Brearley used were

based on nitric acid, and he found this new steel strongly resisted chemical attack. Encouraged, he then experimented with vinegar and other food acids such as lemon juice and found the same results.

Brearley quickly realized this new mix would have a greater product usage than just rifle barrels. He was from Sheffield, England, so he turned to a product the region was known for: cutlery. Up until this point, table cutlery was either silver or nickel plated while cutting knives were made from carbon steel that had to be washed and dried after each use. Then, the rust spots had to be rubbed off prior to the next use.

> On his own initiative, Brearley, found local cutler R.F. Mosley, introduced him to what he called "rustless steel" and had Mosley produce

knives. When the knives would not stain in vinegar, it was Mosley's cutlery manager Ernest Stuart who called the new knives "stainless steel."

of Stainless Steel

The following year in Germany, Krupp was also experimenting by adding nickel to a similar melt. The Krupp steel was more resistant to acids, softer and more ductile making it easier to work.

From these two inventions in England and Germany just prior to World War I, the 300 series austenitic and 400 series martensitic steels were developed.

However, the discoveries and credits came full circle in 1924 when Mr. Brearley's successor at Brown Firth Laboratories, Dr. W.H. Hatfield invented 18/8 stainless steel. Containing 18% chromium and 8% nickel, it is commonly known today as 304 stainless steel.



What is stainless steel? Stainless steel is not a single alloy, but a part of a large family of alloys with different properties for each member. The stainless steel family is quite large and specialized. There are hundreds of grades and sub grades, and each is designed for a special application.

What exactly is required for iron to be transformed into stainless steel? Chromium is the magic element. Stainless steel must contain at least 10.5% chromium to provide adequate resistance to rusting. And, the more chromium the alloy contains, the better the corrosion resistance. However, it is important to remember there is an upper limit to the amount of chromium the iron can hold. Because of this, additional alloying elements are necessary to develop corrosion resistance to specific medias. By definition, stainless steel must contain a minimum of 50% iron. If it contains less iron, the alloy is named for the next major element. For example, if the iron is replaced with nickel, so the iron is less than 50%, it is identified as a nickel alloy. The magic element of chromium imparts a special property to the iron that makes it corrosion resistant. When the chromium is in excess of 10.5%, the corrosion barrier changes from an active film to a passive film. In this process, while the active film continues to grow over time in the corroding solution until the base metal is consumed, the passive film will form and stop growing. This passive layer is extremely thin, in the order of 10 to 100 atoms thick, and is composed mainly of chromium oxide. The chromium oxide prevents further diffusion of oxygen into the base metal.

However, chromium can also be stainless steel's Achilles' heel, and the chloride ion stainless steel's nemesis. This is because in the passive layer, the chloride ion combines with chromium forming a soluble chromium chloride. As the chromium dissolves, free iron is exposed on the surface and reacts with the environment forming rust. However, alloying elements like molybdenum will minimize this reaction.

Other elements, as illustrated in Table I, may be added for specialized purposes. For example: high temperature oxidation resistance, sulfuric acid resistance, greater ductility, high temperature creep resistance, abrasion resistance, or high strength.

Again, of all these elements, only chromium is required for stainless steel to be stainless.



Chromium	Oxidation Resistance	
Nickel	Austenite former - Increases resistance to mineral acids Produces tightly adhering high temperature oxides	
Molybdenum	Increases resistance to chlorides	
Copper	Provides resistance to sulfuric acid Precipitation hardener together with titanium and aluminum	
Manganese	Austenite former - Combines with sulfur Increases the solubility of nitrogen	
Sulfur	Austenite former - Improves resistance to chlorides Improves weldability of certain austenitic stainless steels Improves the machinability of certain austenitic stainless steels	
Titanium	Stabilizes carbides to prevent formation of chromium carbide Precipitation hardener	
Niobium	Carbide stabilizer - Precipitation hardener	
Aluminum	Deoxidizer - Precipitation hardener	
Carbon	Carbide former and strengthener	

#### Table I: Stainless Steel Alloying Elements and Their Purpose

# Steel Classification

#### Table II: Metallurgical Characteristics

There are five classes of stainless steel: austenitic, ferritic, martensitic, duplex, and precipitation hardening. They are named according to how their microstructure resembles a similar microstructure in steel. The properties of these classes differ but are essentially the same within the same class. Table II lists the metallurgical characteristics of each class of stainless steel.

Austenitic	Non-magnetic Non-hardenable by heat treatment Single phase from 0° (K) to melting point Crystallographic form – face centered cubic Very easy to weld	
Ferritic	Magnetic Non-hardenable by heat treatment Crystallographic form – body centered cubic Low carbon grades easy to weld	
Duplex	Magnetic Non-hardenable by heat treatment Contains both austenite and ferrite Easy to weld	
Martensitic	Magnetic Heat treatable to high hardness levels Crystallographic form – distorted tetragonal Hard to impossible to weld	
Precipitation Hardening	Magnetic Crystallographic form – martensitic with microprecipitates Heat treatable to high strength levels Weldable	

Characteristics	Non-magnetic, Usually Very ductile Work hardenable Lower strength Not subject to 885°F (475°C) embrittlement Not subject to ductile – brittle temperature range Not subject to hydrogen embrittlement Will chloride stress corrosion crack
Examples	Type 304, 304L, 304H, 304N, 304LN, 321, 347 Type 316, 316L, 316H, 316N, 316LN, 316Ti Type 317, 317L, 317LM, 904L AL6XN, 254 SMO, 25-6Mo, 1925hMo Type 308, 309, 310



#### Austenitic Stainless Steel:

These are the most popular of the stainless steels because of their ductility, ease of working and good corrosion resistance. All were derived from the 18Cr-8Ni stainless steels. Their corrosion resistance may be compared to the rungs on a ladder with Type 304 on the first rung and the other grades occupying the successive rungs. The most common grade is Type 304 or

304L, which makes up over 60% of all the stainless steel made in the United States today. The other grades are developed from the 18–8 base by adding alloying elements to provide special corrosion resistant properties or better weldability. For example, adding titanium to Type 304 makes Type 321, the workhorse of the intermediate temperature materials. Adding 2% molybdenum to Type 304 makes Type 316, which has better chloride corrosion resistance. Adding more chromium gives Type 310 the basis for high temperature applications. The major weakness of the austenitic stainless steels is their susceptibility to chloride stress corrosion cracking. Table III lists characteristics, properties and examples of these alloys.

#### **Ferritic Stainless Steel:**

Until the early 1980s, these alloys were not very popular because the inherent high carbon content made them extremely brittle and imparted relatively poor corrosion resistance. Research in the late 1960s, using vacuum electron beam melting, led to a new class of alloys sometimes called the "Superferritic Stainless Steels" of which E-Brite 26-1<sup>®</sup> was the first. Then in the late 1970s a new steel refining technique, Argon Oxygen Decarburization (AOD), was developed. This technique, together with the addition of titanium or niobium, allowed the commercial development of extremely corrosion resistant grades. Today SEA-CURE® stainless, one of the most popular superferritic alloys, is widely used in marine applithat of titanium. The most widely used ferritic stainless steel is Type 409, a 10.5% Ce alloy with no nickel, used for automotive exhaust systems. Ferritic stainless steels are resistant to chloride stress corrosion cracking, and have high strength. Grades like SEA-CURE stainless have the highest modulus of elasticity of the common engineering alloys, which makes them highly resistant to vibration. Table IV lists characteristics, properties and types of these alloys.

#### Table IV: Ferritic Stainless Steels



#### **Duplex Stainless Steel:**

cations since its corrosion resistance in

seawater is essentially the same as

Although these alloys were developed in 1927, their usefulness was not realized until the 1960s. They are characterized by having both austenite and ferrite in their microstructure, hence the name Duplex Stainless Steel. Duplex stainless steels exist in a narrow nickel range of about 4-7%. A ferrite matrix with islands of austenite characterizes the lower nickel grades, and an austenite matrix with islands of ferrite characterizes the higher nickel range. When the matrix is ferrite, the alloys are resistant to chloride stress corrosion cracking. When the matrix is austenitic, the alloys are sensitive to chloride stress corrosion cracking. High strength, good

Characteristics	Magnetic Contains both austenite and ferrite High strength Subject to 885°F (475°C) embrittlement at temper- atures as low as 600°F (315°C) Subject to hydrogen embrittlement Subject to ductile-brittle temperature embrittlement Resistant to chloride stress corrosion cracking if ferritic network
Examples	Alloy 2205 Carpenter 7-Mo PLUS Ferralium 255, 2507

Table V: Duplex Stainless Steels

corrosion resistance and good ductility characterize them. One alloy, Carpenter 7-Mo PLUS,<sup>®</sup> has the best corrosion resistance against nitric acid of any of the stainless steels because of its very high chromium content and duplex structure. Table V lists the characteristics, properties and examples of these alloys.

#### **Martensitic Stainless Steels:**

These were the first stainless steels developed because of the inability to obtain low carbon steel. Basically, they are stainless tool steels because they use the same hardening and tempering mechanisms. These grades are very common, from the blade in your pocket Swiss Army knife, to the scalpel the surgeon uses when he makes that first incision for a heart bypass operation. Martensitic stainless steels are used in bearing races for corrosion proof bearings and other areas where erosion-

but are infinitely better than the carbon steels they replace. Like carbon tool steels, martensitic stainless steels derive their excellent hardness from the carbon added to the alloy. Their ability to maintain a keen edge comes from their high hardness and corrosion resistance. Table VI lists the characteristics and some examples of these alloys.

Table VI: Martensitic Stainless Steels

corrosion is a problem. These stainless steels are not especially corrosion resistant, barely as good as Type 304,

Characteristics	Magnetic Metallurgical structure is martensite Heat treatable to very high strengths and hardness – stainless tool steel Difficult to weld
Examples	Types 410, 420 Types 440A, 440B, 440C

#### **Precipitation Hardening Stainless Steel:**

These steels are the latest in the development of special stainless steels and represent the area where future development will most likely take place. They are somewhat soft and ductile in the solution-annealed state, but when subjected to a relatively low precipitation hardening temperature, 1000°F (540°C), their strength more than doubles and they become very hard. The metallurgical structure of the common grades is martensitic,

but some of the special high nickel grades are austenitic. The strengthening mechanism comes from the formation of submicroscopic precipitates, which are compounds of aluminum, copper, titanium, or

Table VII: Precipitation Hardening Stainless Steels



molybdenum. These precipitates provide resistance to strain exerted on the structure. The precipitates are so small they can be observed only at extremely high magnifications with special electron microscopes. Their action may be understood by the analogy of a deck of cards to a block of steel. When a force is placed upon the cards, the cards in the deck easily move in response to the force. If the block of steel is given the low temperature aging treatment, small precipitates form, similar to placing sea sand on the surface of the cards. Now, it takes much more force to cause the cards to move; so, the material is much stronger. The primary use of precipitation hardening steels is where high strength and corrosion resistance are required. Aerospace and military applications have dominated the applications in the past, but new uses in instrumentation and fluid control are being found. Table VII lists the characteristics and some examples of these alloys.

## NICKEL BASED

Many consider these alloys to be stainless steel. But if you recall, by definition in order for stainless steel to be stainless steel it must contain a minimum of 50% iron. The iron ratio in nickel based alloys are considerably less than 50%. Within nickel based alloys there are four classifications. Group A is nickel and nickel-copper alloys such as Monel 400; Group B is Chromium bearing alloys as in Hastelloy<sup>®</sup> C-22<sup>®</sup> and C-276; Group C is Nickel-Molybdenum alloys such as Hastelloy B2, B3 and B4; and Group D is Precipitation-hardening alloys as are Monel K-500 and Inconel alloy 718.

The wide range of nickel based alloys available are used for their resistance to corrosion and retention of strength at elevated temperatures. Many severe corrosion problems can be solved through the use of these alloys. However, they are not universally corrosion resistant. The proper alloy must be carefully selected for a specific application. Nickel and nickel based alloys are very resistant to corrosion in alkaline environments, neutral chemicals and many natural environments. In addition, many nickel based alloys show excellent resistance to pitting, crevice corrosion and stress corrosion cracking in chloride environments.

The alloy strength is controlled by the chemical composition and the metallurgical structure. Only the martensitic and precipitation hardening stainless steels can be heat treated to obtain higher strength. Strengthening, or an increase in the ultimate and yield strengths, of the other grades must be achieved by cold working the structure. Heat treatment of the austenitic, martensitic and duplex grades is used to remove residual stress and, in the case of the austenitic stainless steels, to reduce the probability of chloride stress corrosion cracking. Heat treatment is also used to dissolve any undesirable metallurgical phases that may be present.

Heating and cooling the various grades of stainless steel must be done with caution. Be very careful using acetylene, MAP or propane torches to heat the stainless steel. If a reducing flame is used, excessive carbon may be transferred to the metal resulting in the formation of chromium carbide and ultimately, failure of the part.

Before attempting heat treatment of a particular grade of stainless steel, always refer to the heat

## & Heat Treatment

treatment data for that particular grade. For example, slow cooling a high carbon austenitic stainless steel from the solution anneal temperature may lead to precipitation of chromium carbide. This will result in poor corrosion resistance and low ductility. Holding a ferritic or duplex stainless steel within the 885°F (475°C) embrittlement temperature rangewhich can be as low as 600°F (315°C)-may lead to brittleness at room temperature. Heating high chromium, high molybdenum austenitic stainless steel to a temperature below the specified minimum heat-treating temperature, may lead to precipitation of second phase compounds along the grain boundaries. When placed in service, these alloys may corrode or fail because of low ductility problems. Always check on the nature of the alloy before attempting any type of heat treatment. Table VIII (page 8) compares the strengths of selected alloys within the various classes of stainless steel.

Alloy	UNS number	Ultimate strength, psi	Yield strength, psi	Elongation, % minimum	Modulus of elasticity	Hardness typical
Austenitic S	tainless Steel	s				
Type 304	S30400	75,000	30,000	35	29,000,000	80 RB
Type 304L	S30403	70,000	25,000	35	29,000,000	75 RB
Type 316	S31600	75,000	30,000	30	28,000,000	80 RB
Type 316L	S31603	70,000	25,000	35	28,000,000	80RB
AL-6XN	N08367	112,000	53,000	50	27,000,000	90 RB
Ferritic Stain	nless Steels				_	
Type 430	S43000	60,000	30,000	20	29,000,000	85 RB
Type 439	S43035	60,000	30,000	20	29,000,000	90 RB
Type 409	S40900	55,000	30,000	20	29,000,000	85 RB
SEA-CURE	S44660	90,000	75,000	25	31,500,000	95 RB
<b>Duplex Stain</b>	less Steels	_	_	_	_	
Alloy 2205	S31803	90,000	65,000	25	29,000,000	30 RC
7Mo PLUS	S32950	90,000	70,000	20	29,000,000	30 RC
Alloy 255	S32550	110,000	80,000	15	30,500,000	32 RC
Martensitic	Stainless Stee	els, Maximum Sti	ength			
Type 410	S41000	190,000	150,000	15	29,000,000	41 RC
Type 420	S42000	240,000	200,000	5	29,000,000	55 RC
Type 440C	S44050	280,000	270,000	2	29,000,000	60 RC
Precipitation Stainless Steels						
17-7 PH	S17700	210,000	190,000	5	32,500,000	48 RC
17-4 PH	S17400	190,000	170,000	8	28,500,000	45 RC
Custom 455	S45500	230,000	220,000	10	29,000,000	48 RC

Table VIII: Properties of Stainless Steel Alloys, ASTM Minimums, Unless Otherwise Stated

## THE BASICS of Corrosion

#### What is Corrosion?

Technically, corrosion is the tendency of any metal to return to its most stable thermodynamic state. Namely, that is the state with the most negative free energy of formation. More simply stated, it is a chemical reaction of the metal with the environment to form an oxide, carbonate, sulfate, or other stable compound. In most cases, using a different alloy, material, proper coating, or impressed current can prevent corrosion problems. When a metal part fails in service, it is essential to determine the cause of the failure so that the replacement part can be manufactured from the proper alloy to prevent future failure. Many times a failed part is replaced with the same alloy. For example, if a piping system is made from Type 304L stainless steel and it fails by chloride stress corrosion cracking, replacing with the same alloy will assure failure within the same time frame. If a change of alloy is made, say to a 6% Mo stainless steel such as AL-6XN<sup>®</sup>, the piping may last for the lifetime of the system.

Corrosion can be broadly classified in two forms: (1) chemical dissolution of the metal and (2) galvanic, or electrically driven. Abrasion, fretting and erosion sometimes are classified as corrosion mechanisms, but technically they are a mechanical metal removal process as compared to a chemical removal process. Chemical reaction may accompany the mechanical removal process to speed up the dissolution, but the chemical reaction will fit into the two basic forms. Some authorities list other types of corrosion, but the other types generally are modifications of one of the existing corrosion forms. A correct alloy choice for one type of corrosion mechanism may be entirely the wrong choice for another. Therefore, a proper diagnosis of the failure is essential to make the correct material choice.

Within these two basic classifications there are five types of corrosion: (1) general or uniform corrosion; (2) intergranular corrosion; (3) galvanic corrosion, including pitting and crevice corrosion; (4) stress corrosion cracking; and, (5) microbiologically induced corrosion (MIC). Many times, a metal starts to corrode by one mechanism, for example pitting corrosion, and then fails by a second mechanism, stress corrosion cracking.

#### **Basic Corrosion Resistance**

A metal derives its corrosion resistance by forming a protective oxide film on the surface. Metals may be classified in two categories-active and passive, depending on the nature of the oxide film. With active film metals, the oxide film continuously grows until it reaches a limiting thickness then sloughs off, continues to grow, sloughs off-repeating this process until the metal is completely consumed. Examples of metals with active oxides are iron, copper and zinc. Passive film metals form an extremely thin oxide layer, in the order of 10-100 atoms thick, then stop growing. This film remains stable until something upsets the equilibrium. Examples of metals with passive films are stainless steel, titanium, gold, platinum, and silver.

#### **General or Uniform Corrosion**

Uniform corrosion occurs over large areas of the metal surface. This is the most common form of corrosion with steel and copper. It is the easiest form of corrosion to measure, and service lifetime is easy to calculate. This is the only form of corrosion that may be accurately calculated for lifetime before failure and the only corrosion mechanism in



which increased section thickness gives longer life. This type of corrosion is measured by corrosion rate, usually reported as mpy (mils per year), mm/y (millimeters per year), ipm (inches per month), or mg/sdm/yr (milligrams per square decimeter per year). This type of corrosion may be minimized in the active metals by painting the surface, and unexpected failures can be avoided by periodic inspections.

Acid cleaning of metals is an exaggerated example of general corrosion. Every time a copper or carbon steel surface is acid cleaned, the metal walls are thinned due to uniform corrosion. Stainless steel is subject to general corrosion in many acids and some salt solutions. They are not subject to general corrosion in water; therefore, no data is available.

Uniform corrosion can be reduced or even prevented by proper selection of materials that are resistant to the corrosive environment. Certain elements make the alloy more resistant to different media. For example, high chromium content imparts oxidation resistance. Therefore, look for high chromium for use with nitric acid, the higher the better. High chromium is useful for high temperature oxidation resistance; so, any stainless steel is better than carbon steel in elevated temperature applications. High copper content in stainless steel imparts resistance to sulfuric acid, as with Carpenter 20Cb-3,<sup>®</sup> stainless steel. High nickel content gives resistance to reducing acids and produces a tightly adhering oxide film in high temperature oxidation.

A useful tool in determining corrosion resistance is the "Y" of corrosion shown in Figure 1. This chart divides the alloys into three classes: those resistant to oxidizing acids on the left, those resistant to reducing acids on the right, and those resistant to a mixture of the two in the center. Oxidizing acids are those acids that oxidize the metals they come in contact with, and are themselves, reduced in the process. Reducing simply dissolves the metal without a change in valence or a release of hydrogen in the process. Corrosion resistance increases as you move up the chart. This chart indicates relative corrosion resistance.

By using the published tables of general corrosion rates, it is possible to determine the resistance of a given alloy to a given environment. The Corrosion Data Survey or the computer program, Corsur-both published by the National Association of Corrosion Engineers (NACE)-are excellent resources. Alloy selection can be simplified, or at least narrowed down, using these tables.

Corrosion tables are based on isocorrosion curves. An isocorrosion curve for type 316 stainless steel in sulfuric acid is presented in Figure 2 (page 8). This curve shows the variation in corrosion rate with temperature and concentration. Similar curves are available for most alloys in many media, and generally are available from reputable material producers.



Galvanic corrosion occurs whenever two electrically different metals are connected in a circuit and are in an electrically conductive solution. This type of corrosion requires three conditions: two metals that

differ in the galvanic or electromotive series, an electrically conductive path between the metals and both metals submerged in a conductive solution. A variation of galvanic corrosion can occur with passive film metals. If the alloy loses the passive film in one spot, then it becomes active in that area. Now the metal has both passive and active sites on the same surface. This is the mechanism for pitting and crevice corrosion. Table IX is a list of materials and their relative position in the galvanic series.

This table allows selection of metal pairs that are galvanically compatible. In general, when an anode, for example aluminum, is connected to a cathode or noble metal in salt water, the anode will corrode and the cathode will be unaffected.

Pitting corrosion is a form of galvanic corrosion in which the chromium in the passive layer is dissolved leaving only the corrosion prone iron. The voltage difference between

## **GALVANC** Corrosion

#### Table IX: A Simplified Galvanic Series of Metals and Alloys

Metal	Volts	Corresponding Alloy		
	Corroded end (anodic or least noble)			
Magnesium	-1.55	Magnesium		
Aluminum	-1.33	Aluminum		
Zinc	-0.76	Zinc		
Iron	-0.44	Steel, iron, stainless steel (active), alloy C (active)		
Nickel	-0.23	Nickel (active), Alloy 600 (active), Alloy B-2		
Hydrogen	0.00			
Copper	+0.34	Brass, copper, Monel, nickel (passive), alloy 600		
		(passive), stainless steel (passive)		
Silver	+0.80	Silver		
Gold	+1.36	Gold		

However, there is another factor called "area relationship"; if the anode is very large, such as a vessel wall, and the cathode is small like a bolt head, the galvanic action is slight. But, if the anode is small and the cathode is large, the anode will corrode very rapidly.



the passive and active layer on an austenitic stainless steel is +0.78 volts. Acid chlorides are the most common cause of pitting in stainless steel. Chlorides react with chromium to form the very soluble chromium chloride (CrCl<sub>3</sub>). Thus, chromium is removed from the passive layer leaving only the active iron. As the chromium is dissolved, the electrically driven chlorides bore into the stainless steel creating a spherical, smooth wall pit. The residual solution in the pit is ferric chloride (FeCl<sub>3</sub>), which is very corrosive to stainless steel. This is the reason ferric chloride is used in so many of the corrosion tests for stainless steel. When molybdenum and/or nitrogen is used as an alloying element in stainless steel, the pitting corrosion resistance improves. In an attempt to quantify the effect of alloying elements, a relationship of the various elements responsible for corrosion resistance was developed. The resulting equation is called the *Pitting Resistance Equivalent Number*, or PREN. It has a number of different coefficients of which the most commonly used form is detailed on the next page.

#### PREN = %Cr + 3.3(%Mo) + 16(%N)

A PREN of 32 is considered the minimum for seawater pitting resistance.

Three factors influence pitting corrosion: chloride content, pH, and temperature. In general, the higher the temperature and chloride content and the lower the pH, the greater the probability of pitting. For a given chloride content, a higher temperature and lower pH encourage pitting. Conversely, a lower temperature and a higher pH reduce pitting. The worst conditions occur with acid chlorides, and less dangerous conditions occur with alkaline or high pH chlorides. Pitting can occur rapidly once it starts. For example, under the right conditions of chloride content, pH and temperature, a type 304 tube with a .035" (0.89mm) wall thickness will pit through in less than 8 hours.

Increasing the molybdenum in the alloy produces greater resistance to pitting. Therefore high molyb-



denum – high chromium alloys generally provide the best pitting resistance. Figure 3 shows the relationship of pitting, molybdenum content, pH, and chloride content.

**Figure 3:** Pitting corrosion relationship as a function of chloride content, pH and molybdenum content of austenitic chromium alloys. Temperature range, 150-180° F (65-80° C), Pitting is not a problem below the line, but may be severe above the line.

Table X lists alloys within the molybdenum contents shown on the graph. The molybdenum line represents the threshold at which pitting starts. Above the line pitting can occur rapidly while below the line pitting corrosion will not take place. This chart is very helpful in determining the amount of chloride and pH that can be tolerated for a given alloy class.

#### Table X: Alloy grades according to molybdenum content

Molybdenum Content	Applicable Alloys
0	Types 301, 302, 303, 304, 304L, 304N, 304LN, 305, 308, 309, 310, 321, 347
2	Types 316, 316L, 329
3	Types 317, 317L
3.5	Alloy 825
4	Alloy 904L, Types 317LM, 317LMN
6	AL-6XN, 25-6Mo, 254SMO, Alloy G, Alloy G-3
9	Alloy 625

Crevice corrosion is another form of galvanic corrosion, which occurs when the corroding metal is in close contact with anything that makes a tight crevice. Crevice corrosion is usually the first to occur and is predictable as to when and where it will take place. Like pitting, a conductive solution must be present; and, the presence of chlorides makes the reaction proceed at a fast rate. Crevice corrosion depends on the environmental temperature, alloy content and metallurgical category of the alloy. Also, there is a relationship between the tightness of the crevice and the onset time and severity of corrosion. There is a "critical crevice corrosion temperature" (CCCT) below which corrosion will not occur. Figure 4 is a plot of the PREN versus CCCT and metallurgical category. Table XI lists the PREN for some of the more common alloys. These values are based on the lower composition value for each alloy addition; therefore, the results are conservative. The greater the



# CREVICE

#### Table XI: PREN number for Various Alloys

Metallurgical	Alloy	PREN
	Type 304, 304L	18.0
Austenitic	Type 304N, 304LN	19.6
	Type 316, 316L	22.6
	Type 316N, 316LN	24.2
	Type 317, 317L	27.9
	Type 317LMN	31.8
	AL-6XN	42.7
	Alloy 625	46.4
	Alloy C-276	73.9
	20Cb-3	25.6
	Alloy 2205	30.5
Duplex	7-MoPLUS	31.7
	SEA-CURE Stainless	49.5
Ferritic	Type 430	16.0
	Type 439	17.0
	Type 444	23.3

difference between the CCCT and the operating temperature, the greater the probability that crevice corrosion will occur. This chart is very useful in determining the effect of temperature on corrosion by indicating the approximate temperature at which pitting corrosion begins. The effect of temperature on pitting corrosion is not as clear as that for crevice corrosion, but by adding approximately 100° F (60° C) to the CCCT, the approximate temperature at which pitting starts can be determined.

Figure 4: Critical crevice corrosion temperature as a function of the PREN. CCCT will not occur below the temperature indicated. Tests made 6% ferric chloride.



# **INTERGRANULAR**

All metals are composed of small grains that are normally oriented in a random fashion. These grains are each composed of orderly arrays of atoms with the same spacing between the atoms in every grain. Because of the random orientation of the grains, there is a mismatch between the atomic layers where the grains meet. This mismatch is called a "grain boundary." In a typical stainless steel product, there are about 1,000 grain boundaries that intersect a one-inch (25 mm) line drawn on the surface.

Grain boundaries are regions of high-energy concentration. Therefore, chemical or metallurgical reactions usually occur at grain boundaries before they occur within the grains. The most common

reaction is formation of chromium carbide in the heat-affected zone (HAZ) during welding. These carbides, formed along the grain boundaries, are called "sensitization." Because the carbides require more chromium than is locally available, the carbon pulls chromium from the area around the carbon. This leaves a low chromium grain boundary zone and creates a new low



chromium alloy in that region. Now there is a mismatch in galvanic potential between the base metal and the grain boundary; so, galvanic corrosion begins. The grain boundaries corrode, allowing the central grain and the chromium carbides to drop out as if particles of rusty sand. The surface of the metal develops a "sugary" appearance as illustrated in Figure 5. Carbides are formed when heating occurs, such as welding, heat treatment or metal fabrication. Understanding how they form makes it relatively easy to control their formation. For example, always use a low carbon grade of stainless steel when welding is to be done. These grades are very common today since the development of argon oxygen - decarburization (AOD) refining about 25 years ago. Almost all stainless steel is made using this method since it allows very precise control of the alloying elements, and it is possible to routinely obtain carbon levels of approximate 0.025%, a level at which no chromium carbide particles form in the HAZ during welding. These grades are normally designated as "L" grades such as Types 304L, 316L or 317L. Always use the "L" grades if there is any

> chance that the system will be welded. But if the part is to be used continuously at temperatures above 900° F, it will still sensitize over time. The only solution is to use a "stabilized" grade, one in which titanium, columbium (niobium) or both are added to react with the carbon forming stable grains of titanium or niobium carbide thus stabi-

**Figure 5:** Appearance of the surface of stainless steel (magnification 50X) that has undergone intergranular corrosion. This is sometimes called "sugared." lizing the alloy. The type 304 equivalent stabilized with titanium is type 321, and the type 304 equivalent stabilized with

niobium is type 347. Stabilized grades should be used whenever the steel is held for long periods in the temperature range of 800° to 1500° F (425° to 800° C). Sigma or "chi" phase may be minimized by avoiding the temperatures where they form, or by using alloys high in nickel and nitrogen. Figure 6 shows the effect of temperature, time and carbon content on the formation of chromium carbide. It is critical to get past the nose of the carbon content curve as fast as possible. If it is not possible to cool fast enough to get past the nose of the curve, carbide precipitation will occur. Additionally if a part operates within the maximum upper and lower limits of the curve carbide precipitation will also occur.

Chromium carbide is not the only compound that can cause intergranular corrosion. Other compounds are delta ferrite, sigma phase (a chromiumiron compound), chi phase (a chromium-iron-molybdenum compound), and several other compounds that are found less often. Special mention should be made concerning delta ferrite. All stainless steels are compounded to have a certain amount of delta ferrite in the microstructure to minimize micro cracking during cooling of the weld. The Welding Research Council recommends a range of 2-5%, with most welds measuring at 2%. However, when delta ferrite is exposed to high chloride waters including many hot water systems-the chloride begins to attack the delta ferrite corroding it preferentially and leakage occurs.



#### Figure 6:

Effect of carbon on the time required for formation of harmful chromium carbide. Carbide precipitation occurs inside the loop to the right of the various carbon content curves.

## Corrosion Cracking

Stress corrosion cracking (SCC) is one of the most common and dangerous forms of corrosion. Usually it is associated with other types of corrosion that create a stress concentrator that leads to cracking failure. Nickel containing stainless steel is especially susceptible to chloride induced SCC. Figure 7 (page 16) indicates the maximum susceptibility is in the nickel range of about 5-35% and that pure ferritics, such as Types 430, 439, and 409 are immune. The point of maximum susceptibility occurs between 7-20% nickel. This makes types 304/304L, 316/316L, 321, 347, etc., very prone to such failure.

Stress corrosion cracking (SCC) has three components: alloy composition, environment and the presence of tensile stress. All metals are susceptible to stress corrosion cracking, as Table XII (page 16) indicates.



ALLOY	ENVIRONMENT
Aluminum alloys	Air, Seawater, Salt and chemical combinations
Magnesium alloys	Nitric acid, Caustic, Salts, Coastal atmospheres
Copper alloys	Ammonia and ammonium hydroxide, Amines, Mercury
Carbon steel and iron	Caustic, Anhydrous ammonia, Nitrate solutions
Martensitic and precipitation hardening stainless steel	Seawater, Chlorides, Hydrogen sulfide
Austenitic stainless steel	Chlorides, both organic and inorganic, Caustic solutions, Sulfurous and polythionic acid
Nickel alloys	Caustic above 600□F (315□C), Fused caustic, Hydrofluoric acid
Titanium alloys	Seawater, Salt atmospheres, Fused salt

It doesn't take much chloride to cause failure (a few parts per million will do the job) providing that the pH is low and oxygen is present. Temperature is important, and there is a threshold temperature below which the steel will not crack. This is related to the critical pitting temperature; therefore, the threshold temperature increases as the molybdenum content increases. Type 304 may SCC at room temperature, whereas the six percent Mo alloys have a threshold temperature in the range of 450° F (239° C). The stress component is more subtle. First the stress must be tensile, and it must exceed the yield strength of the component. This sounds simple enough, but any time a component is bent or straightened, or when any physical exertion is made to place the material into a fixed shape, the yield strength is exceeded. Next, matters can be complicated by stress multiplication factors. If a pit or other sharp notch is present, the residual stress is multiplied several times resulting in a stress far in excess of the tensile yield strength. Thus, SCC usually starts with pitting or crevice corrosion as a precursor to forming a stress concentrator.

When the cracks form, they usually are transgranular as illustrated in Figure 8. That is, they crack through the grain. Cracking occurs rapidly progressing through the grain, terminating in a feathery clus**Figure 8:** Polished and etched crosssection of stress corrosion cracked stainless steel (magnification 250X) showing the transgranular cracks and feathery appearance of crack tips.

ter of small cracks. This is a characteristic that distinguishes SCC from other types

of cracking.



Using microprobe analysis, or electron dispersive spectroscopy (EDS), on the crack surface to look for the presence of chlorine, we can observe conclusive evidence that SCC has occurred.

### MICROBIOLOGICALLY Influenced Corrosion

Microbiologically influenced corrosion (MIC) is a recently discovered phenomenon. Actually, it is not a separate corrosion mechanism, rather a different agent that causes corrosion of metals. It is not limited to stainless steel as Table XIII (page 16) indicates. Some form of bacteria action attacks most metals. The mechanism is usually general or crevice corrosion under the bacteria colonies as seen in Figure 9 (page 18).

In some cases, the metabolic byproducts react with the environmental solution to create a very corrosive media. An example is the reaction of chlorine in water with the manganese dioxide byproduct from gallionella bacteria on the surface of the stainless steel. This reaction generates hydrochloric acid, which causes rapid pitting of many common grades of stainless steel.

One of the most common forms of MIC is the metabolic byproduct of the sulfur-fixing bacteria that produces sulfurous or sulfuric acid. These bacteria cause rapid corrosion of the lower alloy stainless steels, like Types 304L or 316L, resulting in through wall crevice corrosion under the bacteria colonies.

Other than the use of bactericides, such as chlorine or ozone, the usual solution to this type of corrosion is to use a 6% molybdenum alloy such as AL-6XN<sup>®</sup>, (a superaustenitic stainless steel) or the highly alloyed nickel alloys. Therefore, if MIC corrosion is taking place, it is best to use one of these alloys.

#### Table XIII: Corrosive Microorganisms

ORGANISM	ACTION	PROBLEM
Desulfovibro Clostridium Thiobacillus	Hydrogen sulfide producer (sulfate reducers)	Corrosive to metals Reduces chromates Destroys chlorine Precipitates zinc
Thiobacillus	Produces sulfuric acid	Corrosive to metals
Nitrobacter Nitrosomonas	Produces nitric acid	Corrosive to active film metals
Gallionella Crenothrix Spaerotilus	Converts soluble ferrous ions to insoluble ferric oxide Converts soluble manganese ions to insoluble manganese dioxide	Produces iron oxides and forms crevices Produces manganese dioxide that can form crevices, or can react with chlorine to produce hydrochloric acid

Figure 9: Crevice corrosion under bacteria colony on the inside of a stainless steel tube (magnification 5X)



# Stainless Steel

Stainless steel is normally joined by welding. Welding provides high strength joints with minimum flow restrictions and prevents crevice corrosion, the major concern with screw thread joints. Threaded connectors form tight crevices that often corrode. However, elimination of crevices does not guarantee trouble free operation. Extreme care must be taken during welding, as many installation problems occur because the basic rules of stainless steel welding are violated. These rules include:

- Always use high purity inert welding gases and cover gases. After welding, both the inside and outside weld surfaces should be silver, light gold or straw color at worst. If the welds are black, then corrosion resistance has been compromised.
- If two surfaces are tack welded to hold them in place prior to making the primary weld, make sure the tack welds are well purged with inert gas and free from any oxidation. Oxidation along the edges of the tack welds can lead to a leak path in the weld.

- Always clean the surfaces prior to welding to remove all organic materials, moisture and dirt. These
  contaminants will react either with the chromium to produce chromium carbide or decompose during welding to create hydrogen gas resulting in porosity.
- Always use oxide-grinding wheels, not silicon carbide for any dressing of weld surfaces. The carbide may react with the chromium, which decreases the corrosion resistance of the weld metal.
- Because stainless steel has lower heat conductivity than carbon steel, 30% less heat input generally is required. Also, the welds take longer to cool. Maintain short arc length and use staggered beads for very long welds to reduce heat input.
- The coefficient of thermal expansion for austenitic stainless steel is higher than for carbon steels and ferritic or martensitic stainless steels. Therefore, keep the base metal restraint to a minimum to prevent distortion of the system.
- If multiple weld passes are required, maintain the interpass temperatures at less than 200° F (100° C) to prevent cracking and distortion of the system.
- Avoid crater cracks by controlling the size of the termination weld pool. If crater cracks occur, remove by grinding with an aluminum oxide wheel before proceeding.

#### Specific Requirements for 6% Molybdenum Stainless (AL-6XN)

- Use a weld filler alloy on all field welds-for orbital welds use weld rings, for other welds, wire or weld rings may be used. The filler alloy must have higher molybdenum content than the AL6XN to compensate for alloy dilution on cooling. Typically a 9% Molybdenum alloy (Alloy 625) is used. If Alloy 625 is not available Alloy C 276 (15% Mo) may be substituted.
- Use an inert gas for both the weld and shield gas. Either helium or argon may be used, although argon is normally used. It is acceptable to use 3 - 5% nitrogen additions to both the torch and shielding gas to compensate for the nitrogen lost from the alloy during welding.
- Make sure the heat tint on the tubing is a light straw yellow at the darkest. A silver weld and heat-affected zone are the best. Any darker weld heat tints must be removed before placing in service. Dark blue heat tints are the most susceptible to corrosion. Remove by grinding

followed by acid cleaning/passivation. A poorly cleaned surface may be just as susceptible to attack as the original heat tint.

- Do not preheat the weld unless the material is below 50° F. When the material is below the dew point, allow it to warm up to above the condensation temperature to prevent moisture condensing on the surface. Remember: moisture causes heat tints.
- Ignite the weld within the area to be welded. If that is impossible, grind the ignition point to remove it completely.



## Why "overalloy" AL-6XN weld areas?

Why "over alloy" AL-6XN, weld areas? Because of two words- Intergranular Corrosion. Although AL-6XN is classified as a single phase alloy, when it is melted as in welding, it will solidify as a two phase alloy with 1) Being austenite, and 2) Being chi phase. Chi phase, a chromium-iron-molybdenum compound depletes the grain boundary of molybdenum and chromium reducing corrosion resistance. By over alloying as with alloy 625 weld insert rings, the alloy balance and therefore corrosion resistance is restored to the base alloy. All metals are composed of small grains that normally are oriented in a random fashion. These grains each are composed of orderly arrays of atoms, with the same spacing between the atoms in every grain. Because of the random orientation of the grains, there is a mismatch between the atomic layers where the grains meet. This mismatch is called a grain boundary. In a typical stainless steel product, there are about 1,000 grain boundaries that intersect a oneinch or 25 mm line drawn on the surface.

Grain boundaries are regions of high-energy concentration. Therefore, chemical or metallurgical reactions usually occur at grain boundaries before they occur within the grains. The most common reaction is formation of chromium carbide in the heat-affected zone (HAZ) during welding. These carbides form along the grain boundaries. Because the carbides require more chromium than is locally available, the carbon pulls chromium from the area around the carbon. This leaves a grain boundary zone, low in chromium, creating a new, low chromium alloy in that region. Now there is a mismatch in galvanic potential between the base metal and the grain boundary, so galvanic corrosion begins. The grain boundaries corrode, allowing the central grain and the chromium carbides to drop out as so many particles of rusty sand. The surface of the metal develops a "sugary" appearance. Several compounds may cause intergranular corrosion in addition to chi phase and chromium carbide. Another compound is sigma phase, a chromiumiron compound. Note, these are compounds, not a random mixture or alloy.

These compounds usually are formed when some type of heating occurs, such as welding, heat treatment, or metal fabrication. Understanding how they form makes it relatively easy to control their formation. For example, always use a low carbon grade of stainless steel when welding is to be done. Today these grades are very common ever since the invention of argon - oxygen - decarburization (AOD) refining about 30 years ago. Almost all stainless steel is made by this method since it allows very precise control of the alloying elements, and it is possible to obtain routinely carbon levels in the range of 0.025 percent, a level at which no chromium carbide particles form in the HAZ during welding. These grades normally are designated as "L" grades, like Types 304L, 316L or 317L. Always use the "L" grades if there is any chance that the system will be welded. Another way of controlling the formation of chromium carbide is to use a stabilizing element addition to the stainless steel. These are titanium and niobium (columbium). The Type 304 equivalent with titanium is Type 321, and the Type 304 equivalent with niobium is Type 347. Stabilized grades should be used whenever the steel is held for long periods in the temperature range of 800 to 1500°F (425 to 800°C). Sigma or chi phase may be minimized by avoiding the temperature range where they form, or by using alloys high in nickel and nitrogen.

Welds may be done with standard orbital welding equipment consisting of a solid-state DC power supply, associated cables, and an enclosed weld head. The weld head contains an internal rotor which holds a tungsten elec-

## Welding Equipment

trode, which rotates around the work to do the weld. The portable power supply, which plugs into 115V VAC, controls the entire weld sequence including an inert-gas pre-purge arc strike, rotation delay, rotational speed (RPM), and multiple timed levels of welding current with pulsation. This is followed by a downslope which gradually terminates the current, and a postpurge to prevent oxidation of the heated material. These weld parameters are dialed into the power supply from a weld schedule sheet after determination of the proper parameters from test welds done on tubing samples. Fusion welds with automatic orbital TIG welding equipment is practical on tubing or small diameter pipe in sizes from 1/8 inch OD tubing to 6" schedule 10 pipe, and on wall thicknesses up to 0.154 wall.



AL-6XN is easily weldable with weld parameters, including travel speed (RPM) and weld currents, comparable to 316L stainless steel. Weld appearance is excellent with a smooth, shiny, flat weld bead on both the OD and ID. For welds with weld insert rings, the inserts are simply placed between the two sections to be welded and fusion welded as usual, except for a slight increase in welding current to compensate for the increased thickness of material contributed by the insert ring. These welds also have a pleasing appearance, with a slight crown on the OD and some inner-bead reinforcement.

#### Autogenous (without filler) Welding for 6% Molybdenum Stainless (AL-6XN)

Autogenous welding can be used with the following precautions:

- Use of 3 to 5 volume percent nitrogen in the shielding gas and a post-weld anneal above 2150° F (1180° C) followed by rapid cooling and pickling if a protective atmosphere was not used during annealing.
- The duration of the anneal must be sufficient to re-homogenize the weld segregation.

 The G48-B crevice test can be used to assess the quality of autogenously welded and annealed AL-6XN alloy.

In many applications, a post-weld anneal and pickle may not be possible, as in large vessel fabrication or field welding of piping systems. In these cases, the exposure conditions must be carefully reviewed to determine if autogenous welds are satisfactory. Autogenous AL-6XN welds are more resistant to corrosion than similar welds of types 316L, 317L and 904L. Their corrosion resistance is approximately that of alloy 904L base metal and superior to that of types 316L and 317L base metal.

# SELECTION

When a corrosion problem is encountered, review the solution chemistry to determine if a change can be made to eliminate the corroding condition. For example, if carbon steel is rapidly oxidizing in steam, is it possible to adjust the pH upward and add hydrazine, or one of its derivatives, to combat the dissolved oxygen? If the system is being cleaned with muriatic acid, which is dangerous to stainless steel, can the acid be changed to one more friendly to the stainless steel such as nitric, citric or sulfamic? If the pH is being lowered using carbon dioxide sparging and chloride pitting occurs, can a mineral acid such as sulfuric or phosphoric acid be substituted to prevent acid bubbles from forming on the surface causing crevice corrosion?

If it is not possible to modify the environment, the alloy must be changed. Use the following selection process to narrow down the alloy options. This same procedure can be used in selecting an alloy for the initial design.

- 1. Review the nature of the environment with respect to chemical composition, temperature, pH, and velocity. Always assume the worst-case scenario. Use the corrosion rate charts or tables to determine those alloys with the best uniform corrosion resistance. If the solution is a single composition, selection will be rather easy. If it is a complex solution of two or more components, determine the corrosion rates in each component individually. Keep in mind the corrosion rates may be accelerated or slowed down in each environment. Many complex solutions require the use of corrosion racks with different alloys exposed to a test environment to determine the best alloy.
- 2. Always determine if chlorides are present. If they are-and they usually are-select the best alloy for pitting resistance as a function of pH and chloride content, using the chart in Figure 3 (page 12).
- Next, pick the proper alloy using its *Pitting Resistance Equivalent Number* (PREN) for the temperature based on crevice corrosion; see Figure 4 (page 13).
- 4. Determine the best carbon range to prevent intergranular corrosion using Figure 6 (page 15), or use a low carbon grade as a general rule.
- 5. Finally, pick the best alloy that will not stress corrosion crack based on Figure 7 (page 16).
- 6. Consider the metallurgical and mechanical characteristics of each candidate alloy. If you are not that familiar with each alloy and its limitations, contact a reputable and qualified material producer for assistance. Many tests have been conducted in many environments, and a wealth of information is available. There is an alloy, material or design modification out there that will solve your problem.

#### Conclusion

The correlation between metallurgical factors and corrosion resistance is straightforward. Inclusion of corrosion control and the correct material selection in the design process is the most efficient means of controlling corrosion and therefore high replacement costs, or catastrophic system failure. If corrosion control is not considered in the design stage, the subsequent costs are usually much greater than the initial investment at the onset.

## **TRADEMARK** Acknowledgements

Hastelloy and C-22 are registered trademarks of Haynes International. E-Brite26-1, AL-6XN, 29-4C, AM 350, AM 355 are registered trademarks of Allegheny Ludlum Corporation. SEA-CURE is a registered trademark of Plymouth Tube Company. Carpenter 20Cb-3, Carpenter 7-MoPLUS, Custom 450, Custom 455 are registered trademarks of Carpenter

Technology Corporation.

25-6Mo is a registered trademark of Special Metals Corporation.

254SMO is a registered trademark of AvestaPolarit.

1925hMo is a registered trademark of Krupp VDM.

Ferralium 255 is a registered trademark of Haynes International.

17-78PH, 17-4PH, 13-5PH, 15-8PH are registered trademarks of AK Steel Company.

## References

- 1. Tverberg, J.C., "A Stainless Steel Primer", Flow Control Magazine, August 2000, September 2000, October 2000
- 2. Uhlig, Herbert H., "The Corrosion Handbook", John Wiley & Sons, New York, 1951
- Tverberg, J.C., "Conditioning of Stainless Steel Surfaces for Better Performance", Stainless Steel World, April 1999, Zutphen, The Netherlands
- 4. Zapffe, Carl, "Stainless Steels", The American Society for Metals, Cleveland, Ohio, 1949
- 5. Parr, J. Gordon and Hanson, Albert, "Introduction to Stainless Steel", The American Society for Metals, 1965
- 6. Ibid.
- "Metals and Alloys in the Unified Numbering System", 8th Edition, Society of Automotive Engineers and the American Society for Testing and Materials, HS-1086/DS-56G, January 1999
- 8. Parr and Hanson, Op cit, Ref.4
- 9. Ibid.
- 10. Ibid.
- 11. Ibid.
- 12. Ibid.
- 13. Fontana, Mars G & Greene, Norbert D., Corrosion Engineering, McGraw-Hill Book Co., New York, 1978
- Rockel, M.B., "Use of Highly Alloyed Stainless Steels and Nickel Alloys in the Chemical Industry", ACHEMA Conference, Frankfurt, Germany June 1978
- 15. Kovach, C.W. and Redmond, J.D. "Correlations Between the Critical Crevice Temperature, PRE-Number, and Long-Term Crevice Corrosion Date for Stainless Steels" Paper 267, Corrosion 95, National Association of Corrosion Engineers
- Tverberg, J.C., & Welz, J.T., "Carbon Dioxide Assisted Corrosion of Stainless Steel" International Water Conference, IWC-98-59, Engineers' Society of Western Pennsylvania, October 19-21, 1998
- Tverberg, J.C., Piccow, K., and Redmerski, L. "The Role of Manganese Fixing Bacteria on the Corrosion of Stainless Steel", Paper 151, Corrosion 90, National Association of Corrosion Engineers
- 18. Tverberg, J.C., Op cit, Ref. 2

	N <sup>(2)</sup> less)		~			~	~	5			~	6				4			~	.+	5		~											
	PRE (Stain		23	26	26	28	32	26	32		43	42	41		20	54	51		20	24	35	41	42											
= (weight %) <sup>(1)</sup>	Other							3	δ - ferrite restriction	т		(Nb): 8xC min.; 1.00max.	н <sub>о</sub>		).		3 <b>-</b>		PREN: 50 minimum	Mn: 2.0-4.0	High		Mn: 4.0-6.0		1		W: 0.50-1.00							
	Cu			ï	ï			3.0-4.0	1.0-2.0		0.75	0.5-1.0	0.5-1.5		0.75	0.3-0.6	0.5-1.5		0.10-0.80		1	ē	0.50-1.00											
	Mo	s Steels	2.0-3.0	2.5-3.0	2.5-3.0	3.0-4.0	4.0-5.0	2.0-3.0	4.0-5.0	Steels	6.0-7.0	6.0-6.5	6.0-7.0	Steels	6.7 <sup>(4)</sup>	7.0-8.0	6.5-8.0	s	0.10-0.80	0.05-0.60	3.0-3.5	3.0-5.0	3.0-4.0											
	ï	tic Stainles	10.0-14.0	12.5-15.0	12.5-15.0	11.0-15.0	13.5-17.5	32.0-38.0	23.0-28.0	lo Austenitic Stainless	23.5-25.5	17.5-18.5	24.0-26.0	ic Stainless	25.3 <sup>(4)</sup>	21.0-23.0	26.0-28.0	inless Steel	1.35-1.70	3.0-5.5	4.5-6.5	6.0-8.0	6.0-8.0											
	cr	ion Austeni	16.0-18.0	17.0-19.0	17.0-19.0	18.0-20.0	17.0-20.0	19.0-21.0	19.0-23.0		20.0-22.0	19.5-20.5	19.0-21.0	<b>Mo Austenit</b>	21.8 <sup>(4)</sup>	24.0-26.0	20.5-23.0	<b>Duplex Sta</b>	21.0-22.0	21.5-24.5	22.0-23.0	24.0-26.0	24.0-26.0											
	z	Comm	0.10	0.11	0.11	0.10	0.10-0.20			6%-N	0.18-0.25	0.18-0.22	0.15-0.25	7%-N	0.24 <sup>(4)</sup>	0.45-0.55	0.3-0.4		0.20-0.25	0.05-0.20	0.14-0.20	0.24-0.32	0.20-0.30											
osition	ပ												0.03	0.03	0.03	0.03	0.03	0.07	0.02		0.03	0.02	0.02	10	0.02	0.02	0.02		0.04	0.03	0.03	0.03	0.03	
teel - Compos	EN Number		1.4404	1.4435	1.4435/BN2 <sup>(3)</sup>	1.4438	1.4439		1.4539			1.4547				1.4652			1.4162	1.4362	1.4462	1.4410	1.4501											
tainless S	UNS Number			S31603		S31703	S31726	N08020	N08904		N08367	S31254	N08926		N08367	S32654	S31277		S32101	S32304	S32205	S32750	S32760											
Wrought St	Name		2461	310L		317L	317LMN	Alloy 20	904L		AL-6XN®	254SMO®	25-6MO		AL-6XN PLUSTM	654 SMO®	27-7MO		LDX 2101®	2304	2205	2507	Zeron ® 100											

maximum, unless range or minimum is indicated
 Pitting resistance equivalent number for stainless steels: PREN = %Cr + 3.3[%Mo + 0.5(%W)] + 16%N
 Basler Norm 2
 Nominal composition

Note:

The reference of the PREN is not intended as an endorsement of corrosion resistance or any listed material. It is to be used as a reference only. It is recommended to contact a qualified corrosion engineer for guidance based upon the individual process conditions.

	PREN <sup>(2)</sup> (Ni-Base)	41	45	46	47	47	51	
	Other	Fe: 5.0 max., (Nb+Ta): 3.15-4.15	W: 3.0-4.5	W: 2.5-3.5	Fe: 3.0 max.	Fe: 1.5 max., Al: 0.1-0.4	Fe: 5.0 max., W: 3.0-4.4	
	Cu		•	•	1.3-1.9	0.50		
2	Mo	8.0-10.0	15.0-17.0	12.5-14.5	15.0-17.0	15.0-16.5	15.0-17.0	
	Ni	58.0 min.	Balance	Balance	Balance	Balance	Balance	
	c	20.0-23.0	14.5-16.5	20.0-22.5	22.0-24.0	22.0-24.0	19.0-23.0	cibai oi animia
2000	ပ	0.10	0.01	0.015	0.01	0.01	0.01	100 10 000
~ fam :	UNS Designation	N06625	N10276	N06022	N06200	N06059	N06686	and an
	Name	625	C-276	C-22	C-2000®	Alloy 59	Alloy 686	Motor: (1) move

Wrought Nickel Alloys - Composition = weight %<sup>(1)</sup>

Notes: (1) maximum, unless range or minimum is indicated (2) Pitting Resistance Equivalent number for Ni-base alloys: PREN = %Cr + 1.5(%Mo + %W + %Nb)

	Т	Γ																			Γ
ASTM Specifications		A 351, A 451, A 743, and A 744	A 351, A 451, A 743, and A 744	A 351, A 743, and A 744	A 351, A 743, and A 744	A 351, and A 743		A 351, A 743, and A 744	A 351, A 743, and A 744		A 351, A 743, A 744, and A 890	A 890, A 995	A 890, A 995	A 890, A 995	A 351, A 890, A 995		A 494	A 494	A 494	A 494	
Approximate Wrought	t Austenitic Grades	316	316L	317	317L	Alloy 20	-Mo Austenitic Grades	AL-6XN®	254SMO®	uplex Stainless Steels	1	-	2205	2507	Zeron® 100	st Ni-Base Alloys	625	C 276	C 276	C 276	0000
UNS Designation	Cast	J92900	J92800	J93000	J92999	N08007	Cast 6%	J94651	J93254	Cast D	J93370	J93372	J92205	J93404	J93380	Ca	N26625	N30002	N26455	N30107	
ACI Designation		CF-8M	CF-3M	CG-8M	CG-3M	CN-7M		CN-3MN	CK-3MCuN		CD-4MCu	CD-4MCuN	CD-3MN	CE-3MN	CD-3MWCuN		CW-6MC	CW-12MW	CW-2M	CW-6M	

# Stainless Steel and Nickel Allow Cast Designations

Glanness Gleer a	and Nicker Alloy I liter I			2211112						
Base	Metal	Filler Metal								
Alloy	UNS No.	GMAW/GTAW <sup>(1)</sup>	UNS No.	SMAW <sup>(2)</sup>	UNS No.					
Austenitic St	ainless steels									
316L	S31603	ER 316L	S31683	E 316L	W31613					
		ER 317L	-S31783	E 317L	W31713					
317L	S31703	ER 317L	S31783	E 317L	W31713					
317LMN	S31726	ERNiCrMo-3	N06625	ENiCrMo-3	W86112					
		ERNiCrMo-10	N06022	ENiCrMo-10	W86022					
Alloy 20		ERNiCrMo-3	N06625	ENiCrMo-3	W86112					
	N08020	ERNiCrMo-10	N06022	ENiCrMo-10	W86022					
		ER320LR	N08022	E320LR	W88022					
904L	N08904	ER 385	N08904	E 385	W88904					
6%-Mo Stainless		ERNiCrMo-3	N06625	ENiCrMo-3	W86112					
(254SMO®, AL-6XN®,	S31254, N08367, N08926	ERNiCrMo-4	N10276	ENiCrMo-4	W80276					
25-6Mo)		ERNiCrMo-10	N06022	ENiCrMo-10	W86022					
Duplex Stai	nless Steels									
2101LDX <sup>(3)</sup>	S32101	LDX 2101	-	LDX 2101	-					
		2304	-	2304	-					
		ER 2209	S39209	E 2209	W39209					
2304 (4)	S32304	2304		2304 AC/DC						
		ER 2209	S39209	E 2209	W39209					
2205	S32205	ER 2209	S39209	E 2209	W39209					
2507	S32750	ER2553	S39553	E2553	W39553					
Zeron 100 <sup>(5)</sup>	S32760	-	-	-	-					
Ni-Base	Alloys									
625	N06625	ERNiCrMo-3	N06625	ENiCrMo-3	W86112					
C 276	N10276	ERNiCrMo-4	N10276	ENiCrMo-4	W80276					
Alloy 22	N06022	ERNiCrMo-10	N06022	ENiCrMo-10	W86022					
C-2000	N06200	ERNiCrMo-17	N06200	ENiCrMo-17	W86200					
Alloy 59	N06059	ERNiCrMo-13	N06059	ENiCrMo-13	W86059					
Alloy 686	N06686	ERNiCrMo-14	N06686	ENiCrMo-14	W86026					

#### Stainless Steel and Nickel Alloy Filler Metals

Notes:

- (1) The applicable American Welding Society (AWS) specification for Bare Stainless Steel Welding Electrodes and Rods, e.g., ER316L, is AWS A5.9. The applicable AWS specification for Nickel and Nickel-Alloy Bare Welding Electrodes and Rods, e.g., ERNiCrMo-3 is AWS A5.14.
- (2) The applicable AWS specification for Stainless Steel Electrodes for Shielded Metal Arc Welding, e.g., E316L, is AWS A5.4. The applicable AWS specification for Nickel and Nickel-Alloy Welding Electrodes for Shielded Metal Arc Welding, e.g., ENICrMo-3 is AWS A5.11.
- (3) Proprietary bare wire and electrodes, LDX 2101 and 2304 also used for welding 2101LDX.
- (4) Proprietary bare wire and electrodes, 2304 also used for welding 2304.
- (5) There are no AWS filler metal designated welding products for welding Zeron 100. The manufacturer recommends filler metals available from Lincoln Electric and Metrode Products, Ltd. Consumables for welds left in the "as deposited" condition are designated as "X" grades, i.e., Zeron 100X.